1630 Switch pump power out of Barker Tank into 2nd Rain for Rent Tank.
Check $Q_{TOT} = 26,467$

System Check – System is in low sleep mode –

R1 INF – 1.1 gpm
R2 INF – 2.1 gpm
} Increased pump speed to ~45%.

$Q_{TOT_1} = 34,298$ gal

DT 11/08/02

$Q_{TOT_2} = 22,349$ gal

NUTRIENT TANKS: 145 + 149 gal = 299 gal

ST #1 – 155 gal + 339 gal
ST #2 – 160 gal + 333 gal

1630 P. Thomas offsite.

1645 D. Tretja offsite.

TUESDAY SEPT. 10

0930 D. Tretja onsite.

System check

- LEAK IN SUCTION PIPING OF ST#2 METERING PUMP.
- $Q_{R1} = 1.02$ gpm; $Q_T = 23,308$ gal
  $\Delta = 959$ gal (1.07 GPM)
- $Q_{R2} = 2.38$ gpm; $Q_T = 36,570$ gal
  $\Delta = 2072$ gal (2.3 GPM)
- [redacted] $Q_{BARGE\ TANK} = 5.16$ gpm
  $Q_{MAINPOINT,TOT} = 31339$ gal
  $\Delta = 4,872$ gal
- Nutrient Tanks – Vol = 126 + 128 = 253 gal
  $\Delta = 91$ gal → 2.73 gph (vs. 2 gph)
- Substrate Tanks
  #1 – 147 + 480" → 460 gal
  $\Delta = 34$ gal ⇒ 2.3 GPH ✓
  #2 – 130 + 34" → 396 gal
  $\Delta = 97$ gal ⇒ 6.5 GPH (vs. 5.1 GPH)
- Turn Down to 70-1 Speed Setting

IGNORE SINCE THIS TANK (PUMP) LEAKING OVERNIGHT.

0800 Fixed leak on metering pump suction tubing (Wellmaid section)

Left message w/ Dennis, MWH Labs to see if it is OK if we sample today.

0830 Set up/calibrate instruments for parameter check

Check parameters:

| R1 INF | | R2 INF | |
|---|---|---|---|
| pH | 7.65 | pH | 7.68 |
| ~~cond~~ | | ~~cond~~ | |
| ~~Turb~~ | | ~~Turb~~ | |
| DO | 0.8 mg/L | DO | 1.2 mg/L |
| T | 23.6 °C | T | 23.5 |
| ~~Sal~~ | | ~~Sal~~ | |

| R1 INT | | R2 INT | |
|---|---|---|---|
| pH | 7.58 | pH | 7.61 |
| ~~cond~~ | | ~~cond~~ | |
| ~~Turb~~ | | ~~Turb~~ | |
| DO | 2.2 mg/L | DO | 0.9 mg/L |
| T | 23.3°C | T | 23.9°C |
| ~~Sal~~ | | Sal | |

R1 Eff

pH 7.59

~~cond~~

~~Turb~~

DO 1.0 mg/L

T 23.1°C

~~Sal~~

R2 Eff

pH 7.74

~~cond~~

~~Turb~~

DO 0.7 mg/L

T 23.4 °C

~~Sal~~

★ USING YSI Model 3500 ~~DT~~ Pure pH, T, and YSI Model 51B for DO.

955 Sue Tom Simpson — United Minerals. He has 1 drum of R635 he can sell to us (this is the minimum unit he can offer), it is about 100-150 lb. He estimates about a 7-10 d lead time, and will send me an email w/ pricing.

1250 Collect samples for lab analysis.

Check Q Totalizers: R1 = 23,621, gal, 1.03 GPM
R2 = 37,148 gal, 2.99 GPM

| | |
|---|---|
| INF-1 | 1250 |
| INF-2 | 1253 |
| INF-3 | 1259 |
| Eff-4 | 1255 |
| Eff-5 | 1258 |
| Eff-6 | 1300 |
| Eff-7 | 1302 |

1330 Dropped off samples @ MWH Labs.

1430 – Set up aerator in 1000 gal Tank (due to low D.O. level(s)

→ 1600 Completed

1610 Switching over pumping to third Rain Fur Rent Tank – about 7K gal remains.

Checked $Q_{tot}$ for IBAtank = 3390 gal

WEDNESDAY 8 SEPT. 11

Noticed Baker Tank is essentially empty.

Start pumping down A Eff Tank Influent

to prepare to introduce a CSW.

Figure we can pump 3500 gal into Baker Tank,

will add ~ half this volume today, and add the remainder over the course of the next week or so, while waiting to resume the test.

10:30 – 4:30 TODAY: 6 hr x 5 gal/min x 60 min/hr = 1800 gal

Will speed up pumping rate today to ~ 5 gpm, then reduce back down tonight.

$Q_{P1} \cong 1.5$ gpm — $Q_{SF} = 3.4$ gph

$Q_{P2} \cong 3.5$ gpm — $Q_{SF} = 8$ gph

$Q_{NF} = 30$ gph

Set pump settings as follows

MP SF-1 – 5% speed 1 stroke

MP SF-2 – 100% speed 1 stroke

MP NF – 50% speed 1 stroke

1045 Begin pumping well water into Influent Eq Tank @ ~ 5 gpm

Construct tubing for pressurized air for aerator inside Baker Tank (will use same supply source for BT & Influent Tank)

1445 Collect samples from 2nd and 3rd RAPW for Raw Baker Tanks for HW characterization. Sample # 3--BT-1 is for the 2nd tank and Sample # 4--BT-1 is for the 3rd tank

1515 P. Thomas departs site to take samples to DMA.

1525 Set up to check system parameters.

R1 INF - 1540
pH - 7.49
T - 23.0 °C
DO - 4.0 mg/L

R1 INT - 1550
pH - 8.01
T - 23.9 °C
DO - 1.95 mg/L

R1 Eff 1605
pH - 7.9
T - 29.3 °C
DO - 1.4 mg/L

R2 INF - 1545
pH - 7.59
T - 22.5 °C
DO - 4.0 mg/L

R2 INT 1600
pH - 7.80
T - 22.8 °C
DO - 2.1 mg/L

R2 Eff 1610
pH - 8.12
T - 23.1 °C
DO - 1.9 mg/L

1605 Stop ~~flow~~ pumping well water. Begin recirculation of water through Baker Tank.

Based on Q (from Baker Tanks) into "Influent" Eq Tank, will have Q pumped from Infl Eq Tank @ ~ 1.35 gpm for R2, 1.25 gpm for R1.

$Q_{TOTAL}$ = 25,940 for R1
41,185 for R2

Check Field Stock Quantities.

NUTRIENT TANKS:

V = 160 gal

ST #1: 121 gal + $\frac{32.5"}{12}$ ⇒ 375 gal

ST #2: 50 gal + $\frac{11.5"}{12}$ ⇒ 190 gal

@ 8 gph — 17 h calc.

Turn back settings to 90%, 90% for ST #2 tank.

1700 Offsite. D.T. 2

THURSDAY SEPT. 12

0820 ONSITE

SYSTEM CHECK

$Q_{R1}$ = 0.6 gpm $Q_+$ = 49626 gal

$Q_{R2}$ = 3.7 gpm $Q_+$ = 26638 gal

Flow is so low through R1 since Q pumpout greatly exceeded $Q_{in}$ for 1,000 gal tank, which was ~~down~~ down almost completely. Will need to better balance in & out flows today.

ΔPs through reactors:

| | | |
|---|---|---|
| R1 | INF | 34 psi |
| R1 | INT | 4 psi |
| R1 | EFF | 0 psi |
| R2 | INF | 16 psi |
| R2 | INT | 6 psi |
| R2 | EFF | 0 psi |

Check Tank Volumes:

Nutrient Tanks: 58 + 60 gal = 118 gal OK ✓

ST #1 — 108 gal + $\frac{28"}{12}$ = 327 gal (~2.7 gpd) OK ✓

ST #2 is almost completely drawn down — BEGIN FILLING THIS TANK (~35 gph)

Check up HH Shut off Float

From Balance Tank Pumpout to Influent (check gal) to Tank

1410 Begin pumping groundwater into 1,000 gal Tank

1430 Adjust flows through R1, R2

to achieve ~ 1.2 S in R1, 3.7 in R2 — throttle back flow into R2 increase pump speed.

@ ~~about~~ 80% speed, Q is about 3 gpm into R2, 2 gpm into R1.

P R1 INF is now about 25 psi, P R2 INF is about 18 psi

1000 well water feed is off.

Recirc. ~~Feed~~ Pump from Below Tank to Influent (1000 gal)
Tank shuts off - Float in Tank is working OK.

Increased Metering Pump for ST #1 to 70%, 70% speed/stroke based on Q flow = 2.0 gpm (Q feed should be ~ 4.5 gpm).

Add 3.5 kg $NaAc \cdot 3H_2O$ to 150 gal ST #2, and 9.0 kg $NaAc \cdot 3H_2O$ to 375 gal ST #2.

4-12-02 1300

| | | T | pH | DO |
|---|---|---|---|---|
| R1 | INF | 25 | 7.85 | 2.0 |
| | INT | 24.7 | 7.74 | 1.5 |
| | EFF | 24.7 | 7.77 | 1.1 |
| R2 | INF | 24.7 | 7.83 | ~~2~~ 1.8 |
| | INT | 24.7 | 7.81 | .8 |
| | EFF | 24.9 | 7.76 | .9 |

1345 D. Tigges UNSITE

1600 System Check
$Q_{R1}$ = 1.83 gpm
$Q_{R2}$ = 3.06 gpm
$Q_{T\,R1}$ = 27,424 gal
$Q_{T\,R2}$ = 46,074 gal

Volumes in Nutrient Tanks: 97 gal but on ST #1 - FULL (> MAX)
ST #2 - 98 + 25 1/4" = 296 gal - OK

Based on $Q_{pz} = 3.0$ gpm,
$Q_{feed/substrate} = 6.9$ gpm.
Based on performance @ 90%-95%
overnight $Q > 8$ gph, turn down to
~ 80% shock/stroke.

TO DO'S – FRIDAY

1. TOP OFF NUTRIENT TANKS
2. TURN DOWN FLOW RATE FOR SUBSTRATE PUMPS @ END OF DAY
3. CHECK W/ JOE – BIS – ON MITIGATING CONTACTING OF BIOMASS IN GAC

Sept 13, 2002

1025 Collect Samples for Analyses

| | | |
|---|---|---|
| INF | 1 | 1032 |
| INF | 2 | 1035 |
| INF | 3 | 1037 |
| EFF | 4 | 1039 |
| EFF | 5 | 1041 |
| EFF | 6 | 1045 |
| EFF | 7 | 1050 |

11:00 9-13-02

| | | T | pH | DO |
|---|---|---|---|---|
| R1 | INF | 24.9 | 7.92 | 2.8 |
| | INT | 25.8 | 7.83 | 1.0 |
| | EFF | 26.0 | 7.80 | 1.0 |
| R2 | INF | 24.9 | 7.97 | 2.7 |
| | INT | 25.5 | 7.92 | 1.3 |
| | EFF | 25.7 | 7.85 | 1.0 |

9-16-02

0800 ~~ID~~ Tejas onsite.
Brought 27.5 kg NaAc (anhydrous) to site.

System check.

$Q_{R1}$ = 1.6 GPM, $V_T$ = 36,938 G
$Q_{R2}$ = 2.2 GPM, $V_T$ = 58,825 G

MP # 1 (for ST #1) Not Pumping. GFI was tripped. Water level in this tank is v. low. Need to ~~add~~ make up additional.

Vol Nutrient Tanks is 105 + 110 = 215 gal

Pump Setting is 50 % s/p, 30 % stroke

ST # 2 – 65 + 14.5" → 178.6 gal

Pump setting 60 % s/p, 90 % stroke

1100 Prep to check system parameters

Check calibration of

pH [redacted] on YSI 3500.

Noticed RZ flowmeter [redacted]

not [redacted] recording

flow - May be leaking -

P @ inlet to reactor

is ~ 20 psi – OK.

1130 Checking Parameters

| | pH | T | DO |
|---|---|---|---|
| INF | 7.95 | 23.0 | 0.6 mg/L |
| R1 INT | 7.82 | 23.9 | 0.2 [redacted] mg/L |
| R1 EFF | 0.2 mg/L | 24.5 | 7.81 |
| RZ INT | 7.96 | 23.7 | 0.2 mg/L |
| RZ EFF | 7.89 | 24.2 | 0.[redacted] mg/L |

(DT)

1245 Began adding well water to Influent tank – tank already @ high-high level (Override float switch)

1400 Shw Owens, North Labs.

He can get NO3-N Chem results from 9-11-12 samples – All were ND. He should be able to have NC results tomorrow. Chem-1 NC results from 9-13 are still pending.

1410 Left msg for Charley from Yardley Pump to check on status of Oberdorfer pump order.

1440 Added 7.5 kg Nitrate (Ca(NO3)2 dry) to make up ST # 1 (added 5.375 kg to 375 gal tank, 2.150 kg to 150 gal tank). Added 575 gal water to both tanks

Added 345 gal water to ST # 2

System 8 – 4.5 kg to both (3.22 kg to 375 gal tank, 1.29 kg to 150 gal tank)

1450 Shut off Gen feed into 1,100 gal Influent Tank

1615 System Check —
Nutrient Tanks — 203 gal
ST #1 — Full
ST # 2 — Filling (Top off Tomorrow AM)

~~1615~~

1630 Offsite.

~~To Fire~~

For Tuesday

1. Check Parameters
2. Collect analytical samples
3. Begin working on modifications for new phase
4. Follow ups: ~~Tom~~ Yeardley Pump

Thursday Sept. 17

0800 D. Treanja, P. Timmes on-site.

P. Timmes called to say that the Effluent Eq. Tank had overflowed during the night a little. This is probably due to the high-high float controlling the pump that feeds this tank in recirculation mode. Will troubleshoot this float today.

System check —

Neither flow meter is reading Q, but Q into Eq Tank after reactors seems ok.

Nutrient Tanks

Vol = 87 + 84 gal = 165 gal

Δ = 36 gal ≃ 2.1 gpd

SJ # 1 — Vol = 135 + [redacted] gal

~ 37"

Slow Mark Lvl enroute to site

Today: will isolate "R2" reactors, remove media & clean out to prepare for start-up w/ Penicillium (1 week). During start-up will be monitoring ClO2 disappearance. Will continue to operate R1 system in recirculation mode during this start-up period.

Check Pressures

Infl. Tank Outlet — 30 psi

R1 Infl. — 28 psi | R2 Infl. — 29 psi

R1 Int. — 3.5 psi | R2 Int. — 5 psi

R1 Effl. — 0 psi | R2 Effl. — 0 psi

0820 Shut off flow into R2 System. All flow is now directed through R1. Shut off Substrate feed pump for R2 & nutrient feed. R1 Infl. pressure is now ~ 34 psi

0845 Check Parameters

| | pH | T | DO |
|---|---|---|---|
| [redacted] | | | |
| R2 INF | 7.89 | 20.2 | 0.2 |
| R2 INT | 7.89 | 20.3 | 0.2 |
| R1 EFF | 7.86 | 20.0 | 0.1 |

0900 Begin pumping groundwater into 4000 gal tank. Will pump throughout day to bring up to as ter as possible in Baker Tanks (some water may have left system when 4000 gal tank overflowed)

1020 Shut off groundwater feed.

1130 Begin adding groundwater to 4000 gal influent tank.

1330 Shut off groundwater feed.

Prepare to collect samples

Collect samples for lab analysis (for $CH_3T$, As, $NO_3^-$)

Inf – 1 – 1359
Inf – 2 – 1356
Eff – 4 – 1358
Eff – 6 – 1400

Wednesday Sept 18, 2002

Check parameters

| 9:30 | T | pH | DO |
|---|---|---|---|
| Inf | 22.7 | 7.90 | 0.6 |
| Int | 23.2 | 7.88 | 0.3 |
| Eff | 22.7 | 7.83 | 0.5 |

Thursday Sept. 19, 2002

815 Onsite.

System check. Infl. Feed Pump off. Water in tank #2 (Immed. downstream of reactors) @ HL. Isolation valve for this tank was closed so flow did not recirculate overnight. Opened this valve; water is now circulating.

940 Begin pumping groundwater into influent tank.

1030 Groundwater feed stops.

c. 1130 Replumbed influent feed to R1 vessels. Resumed recirculation flow through R1.

Install new feed pumps for R2 system (currently offline).

1530 Add 300 gal water to nutrient tanks & ≥ 500g $(NH_4)_2PO_4$ to make up tank to [450 mg/L]. Adjust flow settings to ~30%) speed/stroke - appropriate for 1 gpm total flow.

1600 Adjust flow settings on acetate feed for R1 system to reflect 1 gpm flow (Q feed → 2.3 gph. Set pump @ 35% speed/stroke).

1615 Turn on groundwater feed.

To do's -

1. Check up Del Mar on 9-11-02 sampling results. - Has bioassay - waiting for ez70
2. Pump bleach through [illegible] unit
3. ~~Check~~ Repair & troubleshoot chlorination feed pump
4. ~~Scheduling for PIA start-up (test)~~
5. Check up MWH Americas on Tuesday's sampling results

1030 Groundwater feed stops.

c. 1130 Replumbed influent feed to R1 vessels. Resumed recirculation flow through R1.

Install new feed pumps for R2 system (currently offline).

1530 Add 300 gal water to nutrient tanks + ≥ 500g $(NH_4)_2PO_4$ to make up tank to [450 mg/L].
Adjust flow settings to ~~3~~ (30?).
Speed/stroke - adjust/recalculate for 1 gpm total flow.

1600 Adjust flow settings on acetate feed for R1 system to reflect 1 gpm flow (Q feed → 2.3 gph. Set pump Q 5% speed/stroke).

1615 Turn on groundwater feed.

To do's -

1) Check w/ Dal Mar on 9-11-02 sampling results. - Has botch say - waiting for 0220

2) Pump bleach through bleach # CAC unit

3) ~~Check~~ Repair transblastwist distillate feed pump

4) Scheduling for PSA start-up (last)

5) Check w/ Mindy Americas on Tuesdays sampling results

FRIDAY SEPT. 20

0830 ONSITE. START SYSTEM DOWN DUE TO WATER OVERFLOWING INTO TANK OVERNIGHT (FLOAT IDLE H-H NOT SHUT OFF RECIRCULATION PUMP). ALSO NOTICED ΔP THROUGH R1 SYSTEM IS V. HIGH. OPENED UP VESSELS & INSPECT INTERNALS WILL CLEAN OUT COLLECTION PIPING AT OUTLET SINCE MAJOR HEADLOSS MAY OCCUR HERE (NOTICED A LOT OF SOLID MATERIAL HERE WHEN CLEANING OUT R2 VESSELS) ALSO NOTICED HYDROGEN MEDIA DOES NOT HAVE GROOVES OF SLIME LIKE SPONGES DID.

1000 SAW VITTAL. HE SAID WE SHOULD CLEAN OUT PIPING IN R1 SYSTEM, BUT NOT CLEAN OUT MEDIA - RATHER WE SHOULD SPOT THESE REACTORS IN RECIRCULATION THROUGH (SO WE CAN STILL UTILIZE SPL AQUARIA BAGS). THE START-UP TANK. SET THIS EQUIPMENT UP... ALSO, SEE IF WE CAN INSTALL NEW PIPING FOR OUTLET OF VESSELS (TO REDUCE HL).

1445 CHECKED NITRATE / CALCIUM FROM PREVIOUS CHEMICAL ADDITIONS IN START-UP MODE. WILL NEED TO ADD 1.32 kg $NaNO_3$ (anhyd) AND 9.6 g $(NH_4)_2PO_4$ TO THE ~250 gal OF WATER CIRCULATING THROUGH REACTORS.

1515 SYSTEM IS NOW IN RECIRCULATION MODE (2 "R1" REACTORS, THE INOCULATED ONE & THE BACKUP) W/ SMALL START-UP TANK. ADDING IN ACCUMULATOR VIA SUBMERGED AIR LINE TO AIR DIFFUSER (HOOKED UP TO AIR COMPRESSOR)

1600 DEPART SITE.



MONDAY Sept. 23

0830 Arrive onsite.

System is in recirculation mode w/ start-up tank (Reactor 1 A & B)

Prepare To Check System Parameters.

Cannot get pH probe to calibrate to w/i ±0.1 of pH 4, 7, and 10 standards. *

Need to obtain new standards.

0900 Shw Lab. He will meet me tomorrow am w/ battery FTW meter & pH standards.

0915. Check Parameters —

| | T | pH | DO | |
|---|---|---|---|---|
| INF | 26.9°C | 8.23 | 0.2 | Taken from tank |
| INT | 27.2°C | 8.20 | 0.1 | DO |
| EFF | 27.0°C | 8.17 | 0.1 | |

Need to pump down start-up tank & bring in CW to increase D.O.

* pH 4, 10 seem ok. pH 7 off.

1330 Added 1.32 kg $NaNO_2$ (Anhyd) to R1 Start-up Tank.

## INDEX OF CURVE AND REDUCTION TABLES


Table I—SLOPE STAKE

Table II—STADIA CORRECTION AND HORIZONTAL DISTANCES

Table III—TRIGONOMETRIC FORMULAE

Table IV—NATURAL TRIGONOMETRICAL FUNCTIONS

CURVE FORMULAE

Table V—TANGENTS AND EXTERNALS TO A 1° CURVE

USEFUL RELATIONS

Table VI—INCHES TO DECIMALS OF A FOOT

Table VII—MINUTES IN DECIMALS OF A DEGREE

Table VIII—MIDDLE ORDINATES OF RAILS

Table IX—SHORT RADIUS CURVES

Table X—RODS IN FEET, 10THS AND 100THS OF FEET

Table XI—LINKS IN FEET, 10THS AND 100THS OF FEET

9/25/02 10:00 AM

| | T | pH | DO |
|---|---|---|---|
| R1 | | | |
| Tank | 25.4 | 7.82 | .7 |
| INT | 25.4 | 7.55 | .6 |
| EFF | 25.6 | 7.60 | .6 |

R2

| | | | |
|---|---|---|---|
| Tank | 27.6 | 6.67 | .55 |
| int | 27.7 | 6.70 | 1.3 |
| EFF | 28.0 | 6.69 | .95 |

* DID NOT CALIBRATE pH BIF TAKING READINGS. pH read ~6.85 UPON CHECKING ~~CORRECTING~~ AFTER TAKING READINGS

35.5
9x16
99.5

$$\frac{100\ mg\ ClO_4^-}{L} \times \frac{140.46\ mg\ NaClO_4 \cdot H_2O}{99.5\ mg\ ClO_4^-} \times 8.90\ L = 125.6\ g$$

9/26/02 JPL

0930 Parameter Check

pH probe calibration ok — 7.0, 3.95, 10.05 (w/i 0.1)

| | pH | T | DO |
|---|---|---|---|
| R1 INF | 7.79 | 24.0°C | 1.6 mg/L |
| INT | ~~7.95~~ 7.95 | 24.5 °C | 1.0 mg/L |
| EFF | 7.96 | 24.2°C | 0.9 mg/L |
| R2 INF | 6.87 | 25.3 | 0.3 mg/L |
| INT | 6.84 | 25.5 | 1.7 mg/L |
| EFF | 6.88 | 25.4 | 0.2 mg/L |

1010

Collected sample from R2 for $CCl_4$ – analysis.

1015

Measured [$CCl_4^-$] in sample. Reading is > 380 mV, which is < 1 mg/L $CCl_4$ –

1100 Slow Mech Loss. Since we should put reactor 2 (percolate) in aerobic mode & continue to monitor DO's in both reactors. After measuring DO concentrations tomorrow, we should give consideration to oxidizing more NH4+ (esp. if DO levels have increased significantly).

10/2

- check parameters (pH, T, DO) @ end of day
- check volumes in substrate & nutrient tanks @ end of day ≥ Kcarol in book, then top off substrate tanks (w/ water then keijar building tanks)
- check flows, flow tbl, pressure, replenish flow if not w/ ± 10% gpm

DUNN LAB P.U. TRACKER FOR JPL

SYS ON 1 HR 9/9/96

24hr

D.O. T pH

R1 DO T pH
R2
INFLUENT 19.8 8.17 8.28
EFF

INFL 8.1 8.28
EFF 7.3 DO

| | DO | T | pH |
|---|---|---|---|
| | 7 | | |
| | 20 | 21.8 | 8.28 |
| | | | 10.91 |
| | | | 7.8 |

PBR PILOT STUDY PHASE 2 BOOK 2

"Rite in the Rain"®
ALL-WEATHER
FIELD BOOK
No. 350 N

SEPT. 1982

CONTENTS

| REFERENCE | DATE |
|---|---|
| | |
| | |
| | |

THURSDAY SEPT. 26

(SEE NOTEBOOK FOR NOTES UP TO 11 AM)

TO DO'S FOR FRIDAY:

1. MEASURE PARAMETERS ✓
2. INSTALL AIR/VAC VALVE ON WELL INFLUENT LINE ✓
3. PREPARE MANIFESTS (2) FOR MONDAY
4. FILL UP SUBSTRATE TANKS & ADD ACETATE TO PREP FOR MONDAY.

FRIDAY SEPT. 27

0930 Note levels in substrate & nutrient feed tanks.

#1 – FULL

#2 – 12" (lg. tank) + 35 47 gal

NUTRIENT TANKS – 140 gal/ea – OK

CAN TO ADD TO ST'S #1 –

389 gal 0.013 read

~~389 525 0.8 0.9 0.837~~ 0.837 kg



Mass of NaAc (anhy) to add:

150 gal tank – ~~1,48~~ kg mass for 150 gal →

375 gal tank – ~~3.5~~ kg mass for 375 gal →

1000 Checked system parameters

| R1 | T | pH | DO |
|---|---|---|---|
| TANK | 22.0°C | 8.17 | 5.6 mg/L |
| INT | 21.5°C | 8.06 | 4.7 mg/L |
| EFF | 21.8°C | 8.12 | 4.8 mg/L |

| R2 | T | pH | DO |
|---|---|---|---|
| TANK | 22.8°C | 8.20 | .3 mg/L |
| INT | 22.8°C | 8.22 | .3 mg/L |
| EFF | 22.9°C | 8.22 | .1 mg/L |

1010 Slw Losl. Told me to ~~add~~ route to R1 & check DO's @ end of day. He also said we should change out the NaAc soln if it has been sitting for 2 weeks since bacteria will grow inside & we will not have a handle on the [NaAc]

∴ will empty & rinse out ST #2 (both tanks) & ST #1 (small tank).

1030 Measure & add 1.3 kg NaAc (anhyd.) to R1.

1145 Noticed 1 of 2 nutrient tanks also should be cleaned + refilled.

1430 Check R1 D.O. Levels

TANK – 1.8 mg/L
INT – 1.5 mg/L
EFF – 0.95 mg/L

1530 Offsite.



MONDAY SEPT. 30



0645 ONSITE. (ISLAND ENVIRONMENTAL ATTORNEY ON-SITE. THEY ARE ONSITE TODAY TO REMOVE WW FROM 1ST RAIN FOR RENT TANK

0700 NOTICED AERATOR (COMPRESSOR) WAS OFF – ONE TO GO1 BEING TROUBLESH. IT NOT KNOW HOW LONG IT WAS BEEN OFF.

0900 Island Environmental offsite. JPR signs manifests (will stop by w/ photocopies). All but about 14000 gal is measured out of the first Rain For Rent Tank (~ 20,000 gal total). Will assume for practical purposes that this tank is empty.

1000 Pumped out water in Baker Tank through OAC into 1st Rank For Rent Tank

1015 Set up to check system parameters R1 & R2 systems both in recirculation mode w/ start-up tanks. Water is being aerated.

pH probes calibrated ok - 7.00, 4.01, 10.01

| | pH | T | DO |
|---|---|---|---|
| R1 TANK | 8.11 | 18.9°C | 1.5 mg/L |
| INT | 8.16 | 19.2°C | 1.0 mg/L |
| EFF | 8.13 | 19.3°C | 0.9 mg/L |

| | pH | T | DO |
|---|---|---|---|
| R2 TANK | 8.49 | 19.8°C | 4.8 mg/L |
| INT | 8.49 | 20.0°C | 4.6 mg/L |
| EFF | 8.49 | 20.0°C | 4.5 mg/L |

* R2 system could be a bit down tanking, as DO's have increased significantly since Friday. Will not add more NaAc for now, since system should be online later today.

- Will add water today if system is not put in recirculation mode.

1115 Prep to make down NaAc & $(NH_4)_2PO_4$ feed's -

* 1400 2.15 kg anhyd NaAc to each 150 gal substrate Tank & 5.4 kg anhyd NaAc to each "375 gal" tank (note that tank # 2 has a little bit less than the level corresponding to 375 gal - by about 50 gal)

* 1400 511 g $(NH_4)_2PO_4$ to both (1/2 to each) substrate feed tanks.

1345 Measured & added 1315 g NaAc (anhyd) to R2.

1915 offline.

TUESDAY OCT. 1

0845 ONSITE.

BARGE TANK IS PUMPED DOWN AS FAR AS POSSIBLE.

SET UP FOR START-UP. BEGIN PUMPING GROUNDWATER INTO INFLUENT TANK.

FINAL PARAMETER CHECK FOR R1, R2 IN RECIRC. MODE.

pH Probe Calibration Could — 7.02, 3.97, 10.00

| | DO | T | pH |
|---|---|---|---|
| R1 | | | |
| TANK | 0.8 | 20.2 | 8.29 |
| INT | 0.6 | 20.4 | 8.54 |
| EFF | 0.6 | 20.2 | 8.35 |
| R2 | | | |
| TANK | 6.2 | 20.8 | 8.57 |
| INT | 0.6 | 20.6 | 8.57 |
| EFF | 0.15 | 20.9 | 8.56 |



1000 Turn off adv compressor. Pump down start-up tanks in preparation for forward flow.

1115 Forward flow operation through R1 & R2 @ ~1 gpm each begins.

INITIAL SETTINGS:

Pump speed — 15%. ISR

$Q_{R1,TOT} = 0$ gal
$Q_{R2,TOT} = 0$ gal
} Zeroed totalizers @ 1145

INITIAL SETTINGS FOR FEED PUMPS

ALKALINITY #1 — 50% SPI STROKE
#2 — 50% SPI STROKE

BASED ON $Q_f \cong \frac{2}{\text{gph}}$ FOR 1 GPM

NUTRIENT — 40% SPI STROKE

BASED ON $Q_f \cong \frac{1.25}{\text{gph}}$ FOR 2 GPM

1300 Check Pressure Into 10WT of R1 IN2

R1: IN- 15 psi
OUT - 0 psi

R2: IN- 5 psi
OUT- 0 psi

PLAN FOR SAMPLING TOMORROW
AM -
WILL SAMPLE
INF-1 - $NO_3^-$, $Cl_4^-$
INF-2 - Ac
INF-3 - Ac
EFF ~~INF~~-4 - INF-B - $NO_3^-$, $Cl_4^-$, Ac

(19) CONTAINERS
B45

NOTICED ΔP THROUGH GAC UNIT IS V. HIGH - PROBABLY DUE TO HIGH CONC. OF BIOMASS IN RECIRCULATION SYSTEMS. WILL ADD BLEACH TO EQ TANK #1 & PUMP THROUGH GAC UNIT -



RECHECKED ΔP THROUGH GAC
UNIT - 21 psi - IN
15 psi - OUT } Δ = 3 psi

NOT sure if conditions were same during previous reading (i.e. if outlet valve was closed)

1410 Needed to increase motor speed for R1 feed pump to 25%. to increase Q to 1 gpm (pump kept shut off for short time due to high level in EQ Tank 1- was not being pumped out)
BLEP AIR OUT OF LINE - Q INCREASED. REDUCED SPEED BACK TO 15% - Q OK.

1600 Prepare to check parameters -

| | DO | T | pH |
|---|---|---|---|
| INF | 8.0 | 19.9 | 7.30 |
| R1 | | | |
| INT | 2.4 | 19.8 | 8.19 |
| Eff | 2.2 | 19.6 | 8.53 |

| | pH | T | DO |
|---|---|---|---|
| RZ INT | 7.89 | 19.7 | 2.9 |
| EFF | 7.91 | 19.4 | 2.0 |
| RIN EFF | 7.69 | 19.4 | 2.5 |

1645 Check system parameters:

$Q_{R1}$ = 1.1 gpm; $Q_{R1,TOT}$ = 300.5

$Q_{R2}$ = 1.14 gpm; $Q_{R2,TOT}$ = 298.6

PRZ IN = 8 psi

PR1 IN = 18 psi

ST #1 – ~132 gal

ST #2 – ~150 gal

NUTRIENT TANKS – 143 + 146 gal

1650 Offsite.



WEDNESDAY OCTOBER 2

0645 ONSITE

0700 SYSTEM CHECK ΔTIME = 16 hr

$Q_{R1}$ = 0.85 gpm

$Q_{R1\,TOT}$ = 1173.6 Δ = 978.1 gal

$Q_{AV}$ = 0.91 gpm

$Q_{R2}$ = 0.97 gpm

$Q_{R2\,TOT}$ = 1260.8 Δ = 962.2 gal

$Q_{AV}$ = 1.0 gpm

R1 INLET P = 15 psi

R2 INLET P = 11 psi

ST #1 – VOL ≅ 68 85 gal ; $Q_A$ ≅ 1 gph – high

ST #2 – VOL ≅ 72 gal ; $Q_A$ ≅ 4.9 gph – high

NUTRIENT TANKS – VOL = 122 + 125 gal

Δ = 97 gal ; $Q_{AV}$ ≅ 2.6 gph – high

REDUCE SUBSTRATE SETTINGS TO 90%

SUBSTRATE PUMPS TO 90%, 90%

REDUCE NUTRIENT FEED PUMP SETTINGS TO 70%. STROKE / STROKE

12 14

0910 Checking system parameters

pH probe calibration ok +/- 0.05 for all standards

| | T | pH | DO |
|---|---|---|---|
| INF | 18.0°C | 7.30 | 7.4 mg/L |
| R1 INT | 18.4°C | 8.46 | 2.2 mg/L |
| EFF | 17.3°C | 8.61 | 2.0 mg/L |
| R2 INT | 18.0°C | 8.28 | 2.3 mg/L |
| EFF | 17.5°C | 8.48 | 2.2 mg/L |
| EFF | 17.2°C | 8.63 | 2.2 mg/L |

1000 S/W Lost - the SMPD pts are on @ 8.5 - 8.6 & THAT I should check w/ the labs to see if they can add NaOH to samples after they are analyzed the first time (if they require reanalyzation)

1015 S/W Dennis about adding NaOH to Cl$_2$, Ac samples after they are initially analyzed - will check on appropriateness of this for Ac.

1020 Begin collecting samples for labs analysis:

INF-1 - 1023
-2 - 1025
-3 - 1026
EFF-4 1028
-5 - 1031
-6 - 1033
-7 - 1036
-8 - 1038

1055 P. Timmes takes samples to MWH Labs.

1500

| | T °C | pH | DO mg/L |
|---|---|---|---|
| INF | 20.0 | 7.01 | 7.3 |
| R1 INT | 19.9 | 8.37 | 1.5 |
| EFF | 20.0 | 8.61 | 1.6 1.5 |
| R2 INT | 19.9 | 8.39 | 1.5 |
| EFF | 20.1 | 8.50 | 1.2 |
| EFF | 21.8 | 8.28 | 1.8 |

15

@ 1530
Levels in Substrates #1 and #2 ave

#1 55 gal
#2 55 gal

---

THURSDAY OCT. 3

0430 ONSITE

SYSTEM CHECK

$Q_{INF}$ = 1,044 gpm
$Q_T$ = 2786 gal
$\Delta Q_T$ = 1612 / 24 hr = 1,12 gal/hr
$P_{IN}$ = 11 psi

$Q_{IN2}$ = .73 gpm
$Q_T$ = 2468,8 gal
$\Delta Q_T$ = 0,84 gpm
$P_{IN}$ = 18 psi

NUTRIENT TANKS –
110 gal / ea (vs. 122 & 125 gal)
$\Delta$ = 27 gal / 24 hr ≡ 1,1 gal/hr OK

SUBSTRATE TANKS / YESTERDAY @ 1530
#1 – 56 gal (~95 gal) $\Delta$ = 39 gal – ~2.2 gph OK
#2 – 36 gal (~90 gal) $\Delta$ = 54 gal – ~3 gph HIGH



INCR. SPEED OF R2 PERIOD PUMP TO INCR. FLOW TO 1 CPM

TURN DOWN SUBSTRATE #2 METERING PUMP SPEED/STROKE TO 30:1, ~~30~~ :1 ...

| | | | | |
|---|---|---|---|---|
| 1100 | | | | |
| INF | 20.2 | 7.52 | 8.2 | |
| INF | T °C | pH | DO mg/e | |
| $R_1$ INT | 20.9 | 8.41 | ~~1.5~~ 1.3 | |
| EFF | 20.9 | 8.59 | 1.35 | |
| $R_2$ INT | 21.3 | 8.41 | 1.6 | |
| EFF | 21.5 | 8.50 | 1.2 | |
| EFF | 22.7 | 8.54 | 0.7 | |

1500 S/W Dennis Reyes of NMWA Labs & obtained results from 9-17-92 sampling. I also mentioned I would be sampling tomorrow. He said Cl2 & NO3 – results from 10/2/92 may be available tomorrow.